


C Mouse Wireless

Before first installation, fully charge the battery using a 5V/1A USB charging device and the included USB-C cable.



Part functions: (See figures A and B)

- 1 USB-C Port:** Used to charge the mouse. Cover during washing or rinsing. USB-C Port Cover is located on bottom of mouse.
- 2 Charging cable:** Used to charge the mouse.
- 3 USB-C Port Cover:** Used to cover the USB-C port during washing or cleaning.
- 4 POWER button**
- 5 Mode button**
- 6 Scroll wheel**
- 7 LED indicator:** RED: mouse battery is charging; Blinking GREEN: mouse is attempting to pair to USB Dongle (8); Solid GREEN: mouse is paired to USB Dongle (8) and connected to the computer; Blinking BLUE: mouse is attempting to pair via Bluetooth™; Solid BLUE: mouse is paired and connected to the computer via Bluetooth™.
- 8 USB Dongle:** Plugs to a computer USB port. Allows the mouse to connect to the computer wirelessly. The USB dongle comes in the box with each mouse.
- 9 USB-C Port Cover storage:** Keep the USB-C Port Cover (3) in the storage space (9) when it is not in use to cover the USB-C Port (1) during washing and cleaning.
- 10 Sensor Light**

Note: To pair the mouse in RF or Bluetooth mode, it must first be set to the corresponding mode before beginning the pairing process.

Quick Reference Table:

Function	Action
Power ON/OFF	Press & hold the POWER (4) button for 3 seconds
Switch to Bluetooth™ Mode	Short press MODE (5) button; BLUE LED (7) will blink slowly (trying to acquire a known BT device).
Switch to RF (dongle) Mode	Short press MODE (5) button; GREEN LED (7) will flash slowly (trying to acquire a known RF dongle).
Pair to another dongle (RF mode)	Press Left, Right, & Center (wheel) buttons simultaneously → GREEN LED (7) will blink fast (20 sec) → Hold mouse near dongle → Unplug & reinsert dongle to complete pairing
Pair with Bluetooth™ (3.0 or 5.0)	Press & hold MODE (5) button for 3 seconds → BLUE LED (7) will blink fast (120 sec) → Hold mouse near BT device → Select version (3.0 or 5.0)

Note: The mouse is already paired with the USB dongle that comes with it. If you are using this mouse in combination with the Man & Machine Its Cool Flat Wireless, you can use one USB Dongle to operate both devices. Once you have installed the first device with its dongle, connect the other device to the same dongle by following its connected pairing procedure.

Power ON/OFF:

Press and hold the POWER (4) button for 3 seconds to turn the mouse ON or OFF.

Switching Between Modes:

Man & Machine C Mouse Wireless supports both RF mode and Bluetooth™ mode. Use the MODE button to switch between these modes as needed.

Pairing Instructions:

If using RF mode, ensure the dongle is properly connected to the USB port. If using Bluetooth™ mode, select the appropriate Bluetooth™ version during pairing. Follow the Quick Reference Table below for detailed pairing instructions.

Troubleshooting:

If you experience connectivity issues, try the following steps. Ensure the mouse is fully charged. Restart the pairing process following the steps in the Quick Reference Table. Verify that your device supports the selected Bluetooth™ version.

Battery charging:

Remove the USB-C Port Cover (3) to expose the USB-C port (1). Place the USB Port Cover (3) in the USB Port Cover Storage Space (9). Connect USB connector to a 5V/1A USB charging device. LED indicator (7) will turn RED when charging. The LED indicator (7) will turn off when fully charged. Replace the USB-C Port Cover (3) over the USB-C charging port (1). **Note:** The mouse will not work, or may act erratically, if the battery is depleted or low. Charge timely following procedure described above.

Approved cleaning methods

- You can wipe the product with a soft cloth that is non-abrasive such as a microfiber cloth, a disinfecting wipe, a soft brush similar to a paint brush in bristle stiffness or a sponge, but not a scourer of any sort.
- You can rinse the product with soap and water or an approved disinfectant.

Note: Before wiping or rinsing, cover the USB-C port (1) with the USB-C Port Cover (3). Make sure USB-C Port Cover is fully inserted (see Figure A).

Approved disinfectants

- Chlorine based, up to 100,000 ppm (10%) bleach content
- Alcohol based
- Glutaraldehyde based
- Phenol based
- Formaldehyde based, up to 370,000 ppm (37%) formaldehyde content
- Oxidizing, such as Hydrogen Peroxide, up to 30,000 ppm (3%) content
- Quaternary Ammonium, up to 20,000 ppm (2%) content



Restrictions

- Only clean using the cleaning methods and disinfectants described under "Cleaning instructions" in this manual.
- The mouse can not be immersed in liquid.
- Always follow the instructions provided by the cleaning product manufacturer.
- Do not use petroleum based cleaning fluids nor Acetone or abrasive cleaning aids and products.
- Do not expose the product to temperatures below 32°F or above 131°F (below 0°C or above 55°C).
- Do not use temperature or pressure sterilization.

Product warranty statement

Man & Machine, Inc. ("Manufacturer") warrants to the original purchaser (the "Customer") that the products it manufactures ("Product") shall be free from defects in materials and workmanship at the time of shipment. Manufacturer's sole obligation under this Warranty shall be limited to repairing or replacing with the same or comparable item, at its option, free of charge, any product returned to Manufacturer freight prepaid that is deemed to have failed under Manufacturer's warranty. Manufacturer shall have no obligation under this Warranty or otherwise if (1) the Product has been damaged by abuse, negligence, accident, mishandling, lightning or flood, or other natural disasters, (2) the Product has been affected by normal wear and tear, (3) the Product has not been operated in accordance with its operating instructions, (4) the Product has been altered or repaired by anyone outside Manufacturer, (5) adaptations or accessories have been made or attached to the Product which, in Manufacturer's sole determination, have adversely affected its performance, safety or reliability. If a Product should malfunction or fail during the warranty period, contact the original place of purchase for return options. If purchased directly from Man & Machine, Inc., please submit a Return Material Authorization (RMA). This form can be located on our website at <http://www.man-machine.com/returnsreplacements/>. Please complete requested information and provide a detailed description of the problem. Returned Products must include the RMA number clearly marked on the outside of the package. Manufacturer will not be responsible for any unnecessary items included with any returned Product.

This warranty is the exclusive warranty for any product. Manufacturer specifically disclaims any and all other warranties of any kind, express or implied, including any warranties of fitness for a particular purpose or of merchantability. Manufacturer shall not be liable in tort, including negligence or strict liability, and shall have no liability at all for injury to persons or property.

Manufacturer's liability for failure to fulfill its obligation under this limited warranty or any other liability in connection with a product shall be limited to the amount of the purchase price received by manufacturer for the product. The remedies stated in this limited warranty are the customer's exclusive remedies against manufacturer regarding any product. Under no circumstances shall manufacturer be liable for any indirect, incidental, special or consequential damages, including lost profits and revenues, inconvenience or interruptions in operations, or any other commercial or economic losses of any kind. These limitations and disclaimers are not made by manufacturer where prohibited by law. Some states prohibit limitations of warranties and the customer may have additional rights in those states.

All items returned for warranty repair/replacement must be sent freight prepaid and insured to either the original place of purchase or to the Manufacturer, referencing a valid RMA number:

USA & OTHER COUNTRIES

Man & Machine, Inc.
3706 West Street
Landover, MD 20785
Unites States of America

EUROPE

Man & Machine Europe
Tappersweg 10c
2031 ET Haarlem
The Netherlands

All warranty repairs or replacements will be returned freight prepaid by ground service to any destination within the Continental United States and Europe. Charges for repairs/replacements shipped back outside this region are the responsibility of the end user.

Products must be cleaned/sanitized before returning. Returns will not be accepted that have not been disinfected.

USA & OTHER COUNTRIES
1 Year limited warranty

EUROPE
2 Year limited warranty

For current warranty information, visit our website at <http://www.man-machine.com/warranty-statement/>.

The Windows logo is a trademark or registered trademark of Microsoft Corporation in the United States and/or other countries.

Corporate Headquarters
Man & Machine Inc.
3706 West Street
Landover MD 20785 USA
info@mmimd.com | +1 301 341 4900

European Authorized Representative and Importer
Man & Machine Europe
Tappersweg 10c
2031 ET Haarlem The Netherlands
info@mmieu.com | +31 (0) 23 5450185

Copyright Man & Machine, Inc. 2025



www.man-machine.com

