
Operating Manual





Part functions: (See figures A and B)

- **USB-C port:** Used to connect charging cable. Cover using the USB-C Port Cover during washing or rinsing.
- **Battery charging cable:** Used to charge keyboard battery.
- USB-C Port Cover: Used to cover USB-C port during washing or cleaning.
- 4 POWER switch
- Pairing keys: 'ESC' and 'M' keys for RF; 'BLANK' and 'F2' keys for BT pairing.
- LED indicator: RED: keyboard battery is charging; Blinking GREEN: keyboard is attempting to pair to USB Dongle (7); Solid GREEN: keyboard is paired to USB Dongle (7) and connected to the computer; Blinking BLUE: keyboard is attempting to pair via Bluetooth™; Solid BLUE: keyboard is paired and connected to the computer via Bluetooth™.
- **USB Dongle:** Used when using RF connection method to transmit keyboard RF signal to the computer. Located on bottom of the keyboard.

Power ON/OFF:

Slide the POWER (4) switch to the ON or OFF position to turn the keyboard ON or OFF.

Switching Between Modes:

Man & Machine Its Cool Flat Wireless supports both Bluetooth $^{\mathbb{M}}$ mode and RF mode. Use the mode commands outlined below to switch between Bluetooth $^{\mathbb{M}}$ and RF connection.

Pairing Instructions:

If using Bluetooth™ mode, select the appropriate Bluetooth™ version during pairing. If using RF mode, ensure the USB dongle is properly connected to the computer. Follow the Quick Reference Table below for detailed pairing instructions.

Note: To pair the keyboard in Bluetooth^{IM} or RF mode, it must first be set to the corresponding mode before beginning the pairing process.

Quick Reference Table:

Function	Action
Power ON/OFF	Slide the POWER (4) switch to the ON or OFF position
Switch to Bluetooth TM Mode	Press [BLANK] key + F2 simultaneously (5) \rightarrow BLUE LED (6) will turn ON \rightarrow BLUE light will flash slowly while trying to acquire a known BT device
Switch to RF (dongle) Mode	Press [BLANK] key + F1 simultaneously (5) \rightarrow GREEN LED (6) will turn ON \rightarrow GREEN light will flash slowly while trying to acquire a known RF dongle
Pair to another dongle (RF mode)	Press ESC + M keys simultaneously (5) → GREEN LED (6) will blink fast (20 sec) → Hold keyboard near the dongle → Unplug & reinsert the dongle to complete pairing
Pair with Bluetooth TM (3.0 or 5.0)	Press [BLANK] key + F2 simultaneously (5) for 3 seconds → BLUE LED (6) will blink fast (120 sec) → Hold keyboard near BT device → Select version (3.0 or 5.0)

Note: The keyboard is already paired with the USB dongle that comes with it. If you are using this keyboard in combination with the Man & Machine C Mouse Wireless, you can use one USB Dongle to operate both devices. Once you have installed the first device with its dongle, connect the other device to the same

Operating Manual



dongle by following its connected pairing procedure.

Troubleshooting:

If you experience connectivity issues, try the following steps. Ensure the keyboard is fully charged. Restart the pairing process following the steps in the Quick Reference Table. Verify that your device supports the selected BluetoothTM version.

Battery charging:

Use battery charging cable (2). Connect USB-C connector to keyboard (1), connect USB connector to 5V/1A charging device. LED indicator (6) will turn RED when charging. The RED light will go off when fully charged. Remove and store cable for future use. **Tip:** Turn keyboard off when not in use to maximize battery life. **Note:** The keyboard will not work, or may act erratically, if the battery is depleted or low. Charge timely following procedure described above.

Approved cleaning methods keyboard

- You can wipe the product with a soft cloth that is non-abrasive such as a
 microfiber cloth, a disinfecting wipe, a soft brush similar to a paint brush in
 bristle stiffness or a sponge, but not a scourer of any sort.
- You can spray the product with soap and water or an approved disinfectant.
- You can rinse the product with soap and water or an approved disinfectant.

Note: Before wiping, spraying or rinsing, remove cable (2) from port (1) and cover port (1) with USB-C Port Cover (3). Make sure USB-C Port Cover (3) is fully inserted (See figure C).

Approved cleaning methods drape

- You can wipe, spray or rinse the product as described under "Approved cleaning methods keyboard".
- You can immerse the product in soap and water or an approved disinfectant.
- You can expose the product to Hydrogen Peroxide Vapour (HPV).
- You can sterilize the product in an autoclave or thermo disinfector up to 270°F (134°C), (tested 200 cycles).

Approved disinfectants

- Chlorine based, up to 100,000 ppm (10%) bleach content
- Alcohol based
- Glutaraldehyde based
- Phenol based
- Formaldehyde based, up to 370,000 ppm (37%) formaldehyde content
- Oxidizing, such as Hydrogen Peroxide, up to 30,000 ppm (3%) content
- Quaternary Ammonium, up to 20,000 ppm (2%) content.

A

Restrictions

- Only clean using the cleaning methods and disinfectants described under "Cleaning instructions" in this manual
- The product can not be immersed in liquid.
- Always follow the instructions provided by the cleaning product manufacturer.
- Do not use petroleum based cleaning fluids nor Acetone or abrasive cleaning aids and products.
- Do not expose the product to temperatures below 32°F or above 131°F (below 0°C or above 55°C).
- · Do not use temperature or pressure sterilization.

Product warranty statement

Man & Machine, Inc. ("Manufacturer") warrants to the original purchaser (the "Customer") that the products it manufactures ("Product") shall be free from defects in materials and workmanship at the time of shipment. Manufacturer's sole obligation under this Warranty shall be limited to repairing or replacing with the same or comparable item, at its option, free of charge, any product returned to Manufacturer freight prepaid that is deemed to have failed under Manufacturer's warranty. Manufacturer shall have no obligation under this Warranty or otherwise if (1) the Product has been damaged by abuse, negligence, accident, mishandling, lightning or flood, or other natural disasters, (2) the Product has been affected by normal wear and tear, (3) the Product has not been operated in accordance with its operating instructions, (4) the Product has been altered or repaired by anyone outside Manufacturer, (5) adaptations or accessories have been made or attached to the Product which, in Manufacturer's sole determination, have adversely affected its performance, safety or reliability. If a Product should malfunction or fail during the warranty period, contact the original place of purchase for return options. If purchased directly from Man & Machine, Inc., please submit a Return Material Authorization (RMA). This form can be located on our website at http://www.man-

machine.com/returnsreplacements/. Please complete requested information and provide a detailed description of the problem. Returned Products must include the RMA number clearly marked on the outside of the package. Manufacturer will not be responsible for any unnecessary items included with any returned Product.

This warranty is the exclusive warranty for any product. Manufacturer specifically disclaims any and all other warranties of any kind, express or implied, including any warranties of fitness for a particular purpose or of merchantability. Manufacturer shall not be liable in tort, including negligence or strict liability, and shall have no liability at all for injury to persons or property.

Manufacturer's liability for failure to fulfill its obligation under this limited warranty or any other liability in connection with a product shall be limited to the amount of the purchase price received by manufacturer for the product. The remedies stated in this limited warranty are the customer's exclusive remedies against manufacturer regarding any product. Under no circumstances shall manufacturer be liable for any indirect, incidental, special or consequential damages, including lost profits and revenues, inconvenience or interruptions in operations, or any other commercial or economic losses of any kind. These limitations and disclaimers are not made by manufacturer where prohibited by law. Some states prohibit limitations of warranties and the customer may have additional rights in those states.

All items returned for warranty repair/replacement must be sent freight prepaid and insured to either the original place of purchase or to the Manufacturer, referencing a valid RMA number:

USA & OTHER COUNTRIES Man & Machine, Inc. 3706 West Street Landover, MD 20785 United States of America EUROPE
Man & Machine Europe
Tappersweg 10c
2031 ET Haarlem
The Netherlands

All warranty repairs or replacements will be returned freight prepaid by ground service to any destination within the Continental United States and Europe. Charges for repairs/replacements shipped back outside this region are the responsibility of the end user.

Products must be cleaned/sanitized before returning. Returns will not be accepted that have not been disinfected.

USA & OTHER COUNTRIES EUROPE

1 Year limited warranty 2 Year limited warranty

For current warranty information, visit our website at http://www.man-machine.com/warranty-statement/.

Rev. 1.4

The Windows logo is a trademark or registered trademark of Microsoft Corporation in the United States and/or other countries.

Corporate Headquarters

Man & Machine Inc.

3706 West Street

Landover MD 20785 USA

info@mmimd.com | +1 301 341 4900

European Authorized Representative and Importer

Man & Machine Europe
Tappersweg 10c
2031 ET Haarlem The Netherlands
info@mmieu.com | +31 (0) 23 5450185



Copyright Man & Machine, Inc. 2025

