

Simply Cool Touch Keyboard

The Simply Cool Touch is a full size water-resistant and contaminant proof keyboard with integrated two-button touchpad mouse on the right side. This sealed and rigid surface keyboard is value priced for industrial, marine, and medical use, as well as other applications where moisture and cleaning are a consideration. Because the Simply Cool Touch is also quieter than "standard" keyboards, they are great for applications where noise generated from "key-clicks" is a problem. The Simply Cool Touch is compatible with standard keyboard layouts and drivers are not needed.

Weight:

530.0 g (1.2 lb.)

Dimensions:

364 mm x 136 mm x 12.0 mm
14.3" x 5.4" x 0.5"

Cable length:

1.83 m (6')

Storage temperature:

-20 °C - 60 °C
-4 °F - 140 °F

Operating temperature:

0 °C - 60 °C
32 °F - 140 °F

Voltage:

5 Volt

Composition:

100% Silicone Rubber
PVC Cable
100% Latex free

System requirements:

USB interface
(Not PS2 compatible)

Number of keys:

105 US Layout keys with keypad.

Warranty period:

One year replacement warranty.

*Specifications subject to change
without notice*

Installing Your Simply Cool Touch Keyboard

USB: Attach the keyboard cable to the computer USB port. (You do not have to turn off your computer. There is no software to install.)

You can email us at: info@mmimd.com
or call us at: (301) 341-4900
In Europe, contact +31-23-5450185
www.man-machine.com



Cleaning Instructions for Waterproof Keyboards and Mice:

1. Clean the surface of the product by wiping, brushing, spraying or dipping it. Use only rags, sponges or soft bristle brushes. **DO NOT place the USB connector into the fluid.**
2. Either wipe with dry cloth or allow to air dry.

Disinfectants recommended by Man & Machine, Inc.:

- **Chlorine based (max 10% solution)** - Chlorox, Novalsan, etc.
- **Formaldehyde based** - Formaldehyde Solution 37%, Vinco Formaldegen, etc.
- **Glutaraldehyde based** - Aldacide 200, Lysofume, Wavicide, etc.
- **Phenol based** - Lysol I.C., Beaucoup, Magna Clean, Tek-Trol, etc.
- **Alcohol based** - Cavicide, Isopropyl Alcohol, Medicide, Dürr FD 322, FD 333 and FD 350, etc.
- **Oxidizing** - Hydrogen Peroxide 3% Solution, Lifeguard Series, etc.
- **Quaternary Ammonium** - Roccal-D, Bacto-Sep, Parvosol, Dürr FD 300 2%, Dürr FD 312 2%, etc.
- **Soap and water**

DO NOT USE:

- **Petroleum based cleaning fluids, such as Gasoline**
- **Acetone**
- **Over 10% bleach solutions**
- **Temperature or pressure sterilization**
- **Buffing pads or scrubbing pads**

THESE INSTRUCTIONS AND RECOMMENDATIONS HAVE BEEN PREPARED TO ADVISE THE PROPER METHODS FOR CLEANING YOUR PRODUCT. MAN & MACHINE, INC. OR THE LOCAL DISTRIBUTOR CANNOT ASSUME ANY RESPONSIBILITY FOR THE APPLICATION OF THEM. IF THERE ARE ANY QUESTIONS, PLEASE CONTACT PLACE OF PURCHASE OR MMI PRIOR TO CLEANING.