

## B Cool Keyboard

The B Cool washable keyboard is Man & Machine's answer to people who want a water-resistant keyboard at an economical price. The B Cool is a less expensive alternative to our truly waterproof models. The B Cool has low-profile keys which makes the touch and feel of the keycaps exceptional. It takes up little space, easy to clean, and comes with all the passion, commitment and support that you expect with any of our "cool" products.

**Weight:**  
430 g (0.9 lb.)

**Dimensions:**  
377.0mm x 123.0 mm x 27.0 mm  
(14.84" x 4.84" x 1.06")

**Cable length:**  
1.44 m (4.75')

**Voltage:**  
5 Volt

**System requirements:**  
USB interface

**Number of keys:**  
108 = US Layout with  
Windows™

**Warranty period:**  
One-year limited warranty

*Specifications subject to  
change without notice*

### Installing Your B Cool Keyboard



**USB:** Attach the keyboard cable to a USB computer port. (You do not have to turn off your computer. There is no software to install.)

You can email us at: [info@mmimd.com](mailto:info@mmimd.com)  
or call us at: (301) 341-4900  
In Europe, contact +31-23-5450185  
[www.man-machine.com](http://www.man-machine.com)



Copyright Man & Machine, Inc. 2010

### Cleaning Instructions for B Cool Keyboard:

1. Lock the keyboard by pressing the Lock key  (above the Num Lock key) for about three seconds.
2. Clean the surface of the product by wiping, brushing or spraying. Use only rags, sponges or soft bristle brushes.  
**DO NOT place the USB connector into the fluid.**
3. Either wipe with dry cloth or allow to air dry.
4. Keyboard can also be rinsed or submersed. After cleaning, drain, and turn upside down on dry towel and allow to air dry.
5. After you finished cleaning press the Lock key  for three seconds to unlock the keyboard.

### Disinfectants recommended by Man & Machine, Inc.:

- Chlorine based (max 10% solution) - Chlorox, Novalsan, etc.
- Formaldehyde based - Formaldehyde Solution 37%, Vinco Formaldegen, etc.
- Glutaraldehyde based - Aldacide 200, Lysofume, Wavicide, etc.
- Phenol based - Lysol I.C., Beaucoup, Magna Clean, Tek-Trol, etc.
- Alcohol based - Cavicide, Isopropyl Alcohol, Medicide, etc.
- Oxidizing - Hydrogen Peroxide 3% Solution, Lifeguard Series, etc.
- Quaternary Ammonium - Roccal-D, Bacto-Sep, Parvosol, etc.
- Soap and water

### DO NOT USE:

- Petroleum based cleaning fluids, such as Gasoline
- Acetone
- Over 10% bleach solutions
- Temperature or pressure sterilization
- Buffing pads or scrubbing pads

THESE INSTRUCTIONS AND RECOMMENDATIONS HAVE BEEN PREPARED TO ADVISE THE PROPER METHODS FOR CLEANING YOUR PRODUCT. MAN & MACHINE, INC. OR THE LOCAL DISTRIBUTOR CANNOT ASSUME ANY RESPONSIBILITY FOR THE APPLICATION OF THEM. IF THERE ARE ANY QUESTIONS, PLEASE CONTACT PLACE OF PURCHASE OR MMI PRIOR TO CLEANING.

MAN & MACHINE DOES NOT CONSIDER THE B COOL KEYBOARD TO BE A MEDICAL KEYBOARD FOR INFECTION CONTROL PURPOSES DUE TO THE INABILITY TO MECHANICALLY CLEAN ALL SURFACES AND AREAS ON THE KEYBOARD.