

Man & Machine, Inc.

Cleaning Instructions for Waterproof Keyboards and Mice:

1. Disconnect the keyboard/mouse.
2. Clean the surface of the product by wiping, brushing, spraying or dipping it. Use only rags, sponges or soft bristle brushes. **DO NOT** place the USB or PS/2 connector into the fluid.
3. Either wipe with dry cloth or allow to air dry.
4. Reconnect the keyboard/mouse.

Disinfectants recommended by Man & Machine, Inc.:

- Chlorine based (*max 10% solution*) - *Chlorox, Novalsan, etc.*
- Formaldehyde based - *Formaldehyde Solution 37%, Vinco Formaldegen, etc.*
- Glutaraldehyde based - *Aldacide 200, Lysofume, Wavicide, etc.*
- Phenol based - *Lysol I.C., Beaucoup, Magna Clean, Tek-Trol, etc.*
- Alcohol based - *Cavicide, Isopropyl Alcohol, Medicide (POL-0.3), etc.*
- Oxidizing - *Hydrogen Peroxide 3% Solution, VikronS, Lifegard Series, etc.*
- Quaternary Ammonium - *Roccal-D, Bacto-Sep, Ascend, Parvosol, etc.*
- Soap and warm water

DO NOT USE:

- **Petroleum based cleaning fluids, such as Gasoline, Turpentine or oil**
- **Acetone**
- **Over 10% bleach solutions**
- **Temperature or pressure sterilization**
- **Buffing pads or scrubbing pads**

THESE INSTRUCTIONS AND RECOMMENDATIONS HAVE BEEN PREPARED TO ADVISE THE PROPER METHODS OF CLEANING YOUR DATA ENTRY PRODUCT. MAN & MACHINE, INC. OR THE LOCAL DISTRIBUTOR CANNOT ASSUME ANY RESPONSIBILITY FOR THE APPLICATION OF THEM. IF THERE ARE ANY QUESTIONS, IT IS IMPORTANT THAT, PRIOR TO THE ACTUAL CLEANING, OUR OFFICE IS CONTACTED FOR FURTHER INFORMATION.

You can email us at: info@mmimd.com or call us at: (301) 341-4900.

Nov 29, 2006