



## Part functions: (See figure A.)

- Micro USB port: Used to charge the mouse. Cover during washing or rinsing. Cover is located on bottom of mouse.
- Charging cable: Used to charge the mouse.
- USB Port cover: Used to cover the Micro USB port during washing or cleaning.
- 4 Power button
- Scroll Wheel
- **LED indicator:** Red: mouse battery is charging; blinking blue: mouse is trying to pair; solid blue: mouse is in paired mode and connected to computer.
- **USB Dongle:** Plugs to a computer USB port. Allows the mouse to connect to the computer wirelessly. The USB Dongle comes in the mouse box with each mouse.
- USB Port cover storage space: Keep the USB Port Cover in the storage space when it is not used to cover micro USB port.
- Sensor Light

### Installation: (See figure B.)

Before first installation, fully charge the battery using a 5V/1A USB charging device and the included micro-USB cable. Plug the USB Dongle (7) into a computer USB port. Each dongle is already paired with it's own mouse. Turn the mouse on (4). Wait for mouse to pair automatically.

If you are using this mouse in combination with a Man & Machine Wireless Its Cool keyboard or Wireless Its Cool Flat keyboard, you can use one USB dongle to connect both devices. Once you have installed the first device and it is paired, follow the pairing procedure to connect the other device to the same dongle.

### Pairing: (See figure A.)

The mouse is already paired with the USB dongle that comes in the mouse box. To pair the mouse with another dongle or to re-pair it with the dongle it came with: turn on the mouse by pressing the power button (4). Press the Scroll Wheel (5) and the Right Mouse Button at the same time to put the the mouse in pairing mode. When the mouse is in pairing mode, the Blue LED (6) will blink. If the USB dongle is plugged in, unplug the USB dongle and plug it back to the PC. Keep the mouse close to the USB dongle. Once the mouse is paired and connected to the PC, the Blue LED will turn solid blue (6). **Note:** The mouse will not work if it has lost it's pairing. Loss of pairing is signaled by blinking blue light (6). Follow procedure described above to restore pairing.

#### Battery charging: (See figure A.)

Connect the charging cable (2) Micro USB connector side to the mouse and connect the USB A connector side to a 5V USB charging device or a powered USB computer port. The Red LED (6) will stay on while charging. The Red LED will go off when the battery is fully charged. Remove and store the charging cable for future use.

**Note:** If the sensor red light at the bottom of the mouse doesn't come on, charge the battery following the procedure described above.

**Note:** The mouse will not work if the battery is empty. Charge timely following procedure described above.

Note: Only use the included micro-USB cable to charge.

#### **Approved cleaning methods**

- You can wipe the product with a soft cloth that is non-abrasive such
  as a microfiber cloth, a disinfecting wipe, a soft brush similar to a paint
  brush in bristle stiffness or a sponge, but not a scourer of any sort.
- You can spray the product with soap and water or an approved disinfectant.
- You can rinse the product with soap and water or an approved disinfectant. Before rinsing, cover port (1) with cover (3). Make sure cover (3) is fully inserted (See figure A).

### Approved disinfectants

- Chlorine based, up to 100,000 ppm (10%) bleach content
- · Alcohol based
- Glutaraldehyde based
- Phenol based

# Operating Manual



- Formaldehyde based, up to 370,000 ppm (37%) formaldehyde content
- Oxidizing, such as Hydrogen Peroxide, up to 30,000 ppm (3%) content
- Quaternary Ammonium, up to 20,000 ppm (2%) content.



### Restrictions

- · Only clean using the cleaning methods and disinfectants described under "Cleaning instructions" in this manual.
- The mouse can not be immersed in liquid.
- Always follow the instructions provided by the cleaning product manufacturer.
- Do not use petroleum based cleaning fluids nor Acetone or abrasive cleaning aids and products.
- Do not expose the product to temperatures below 0 °C or above 55 °C.
- Do not use temperature or pressure sterilization.

## Product warranty statement

Man & Machine, Inc. ("Manufacturer") warrants to the original purchaser (the "Customer") that the products it manufactures ("Product") shall be free from defects in materials and workmanship at the time of shipment. Manufacturer's sole obligation under this Warranty shall be limited to repairing or replacing with the same or comparable item, at its option, free of charge, any product returned to Manufacturer freight prepaid that is deemed to have failed under Manufacturer's warranty. Manufacturer shall have no obligation under this Warranty or otherwise if (1) the Product has been damaged by abuse, negligence, accident, mishandling, lightning or flood, or other natural disasters, (2) the Product has been affected by normal wear and tear, (3) the Product has not been operated in accordance with its operating instructions, (4) the Product has been altered or repaired by anyone outside Manufacturer (5) adaptations or accessories have been made or attached to the Product which, in Manufacturer's sole determination, have adversely affected its performance, safety or reliability. If a Product should malfunction or fail during the warranty period, contact the original place of purchase for return options. If purchased directly from Man & Machine, Inc., please submit a Return Material Authorization (RMA). This form can be located on our website at http://www.man-machine.com/ returns replacements/. Please complete requested information and provide a detailed description of the problem. Returned Products must include the RMA number clearly marked on the outside of the package. Manufacturer will not be responsible for any unnecessary items included with any returned Product.

This warranty is the exclusive warranty for any product. Manufacturer specifically disclaims any and all other warranties of any kind, express or implied, including any warranties of fitness for a particular purpose or of merchantability. Manufacturer shall not be liable in tort, including negligence or strict liability, and shall have no liability at all for injury to persons or property. Manufacturer's liability for failure to fulfill its obligation under this limited warranty or any other liability in connection with a product shall be limited to the amount of the purchase price received by manufacturer for the product. The remedies stated in this limited warranty are the customer's exclusive remedies against manufacturer regarding any product. Under no circumstances shall manufacturer be liable for any indirect, incidental, special or consequential damages, including lost profits and revenues, inconvenience or interruptions in operations, or any other commercial or economic losses of any kind. These limitations and disclaimers are not made by manufacturer where prohibited by law. Some states prohibit limitations of warranties and the customer may have additional rights in those states.

All items returned for warranty repair/replacement must be sent freight prepaid and insured to either the original place of purchase or to the Manufacturer, referencing a valid RMA number:

**USA & OTHER COUNTRIES EUROPE** 

Man & Machine, Inc. Man & Machine Europe 3706 West Street **Tappersweg 10c** Landover, MD 20785 2031 ET Haarlem

All warranty repairs or replacements will be returned freight prepaid by ground service to any destination within the Continental United States and Europe. Charges for repairs/replacements shipped back outside this region are the responsibility of the end user.

Products must be cleaned/sanitized before returning. Returns will not be accepted that have not been disinfected.

**USA & OTHER COUNTRIES EUROPE** 

1 Year limited warranty 2 Year limited warranty

For current warranty information, visit our website at http://www.man-machine.com/warranty-statement/.

rev. 1.2

The Windows logo is a trademark or registered trademark of Microsoft Corporation in the United States and/or other countries.









USA:

info@mmimd.com

+1 301 341 4900

Europe:





# • Refund Policy



# Refund Policy

Orders may be returned within 30-days for full refund (shipping not included). Return requests received after 30-days will require additional approval and a 30% restocking fee. Units used for biological or industrial applications CANNOT be returned for refund. All units returning for refund must be in "like new" condition with original packaging and accessories (i.e. cables, dongles, etc.).

rev. 1.2

MAN & MACHINE





The Windows logo is a trademark or registered

trademark of Microsoft Corporation in the

United States and/or other countries.

